

1. Product instruction: It is designed for photochromic lens testing which could check the color changing fast.

2. Operation instruction:

a. Connect DC adapter

b. The machine starts when press the power button, timer for 30 or 60seconds to choose. Press the third time to power off.

3. Technical Instruction:

a. 15LED

b. Power:24W

c. Wave length:365-405nm

4. Cautions

a. Please read the instruction carefully before using it.

b. Don't allow any liquid into the machine otherwise ,the damage may occur

c. Please unplug the adapter after leaving to prolong its lifetime